




Wing Compressors DISCHARGE AIR TEMPERATURE

(at compressor outlet port ,without after cooler)



* Low outlet temperature (50°C lower than in most other screw compressors on the market)